


Technical Information

Liquiline CM442R/CM444R/ CM448R

Cabinet controller with a maximum of eight measuring channels based on digital Memosens technology



Extensible multiparameter controller for monitoring and controlling processes in industry and the environmental sector

Application

Possible to connect up to 8 Memosens sensors
Mathematic functions calculate new measured values
Digital fieldbuses (HART, PROFIBUS, Modbus, Ethernet/IP)
and integrated web server
A cleaning function, controller and alarm relay can be selected
Optional digital or analog inputs/outputs for signal transmission

The primary applications are:

- Food and beverages
- Life science
- Water and wastewater
- Chemical industry

Your benefits

- Maximum process safety thanks to:
 - Simple menu guidance via optional graphic display
 - Standardized operating concept across all devices from the Liquiline, sampler and analyzer platform
- Fast commissioning thanks to:
 - Memosens: lab-calibrated sensors & hot plug-and-play
 - Preconfigured Liquiline transmitter
 - Easy extension and adaptation
- Minimum inventory:
 - Cross-platform, modular concept (e.g. identical modules irrespective of parameters)
 - Integration into Fieldcare and W@M facilitates effective asset management

Table of contents

Function and system design	4	PFM function	21
Measuring system	4	Auxiliary voltage	21
Application example	5	Test voltage	21
		Cable specification	21
Device architecture	6	Current outputs, active	21
Slot and port assignment	6	Span	21
Order of the modules	6	Signal characteristic	21
Basic rule for hardware upgrades	6	Electrical specification	21
Determining the hardware delivery status	7	Cable specification	21
Terminal diagram	7	Relay outputs	22
Device configuration using the example of a CM442R- **M1A1F0*	8	Electrical specification	22
Function diagram CM442R	9	Cable specification	22
Device configuration using the example of a CM444R- **M42A1FA*	10	Protocol-specific data	22
Function diagram CM444R	11	HART	22
Device configuration using the example of a CM448R- **26A1*	12	PROFIBUS DP	23
Function diagram CM448R	13	Modbus RS485	23
		Modbus TCP	23
Communication and data processing	14	EtherNet/IP	23
		Web server	24
Dependability	14	Power supply	24
Reliability	14	Supply voltage	24
Maintainability	15	Fieldbus connection	24
Safety	18	Power consumption	24
		Fuse	25
Input	19	Overvoltage protection	25
Measured variables	19	Cable specification for optional display cable	25
Measuring ranges	19	Electrical connection	25
Types of input	19	Connecting optional modules	28
Input signal	19	Protective ground connection	29
Cable specification	19	Sensor connection	30
Digital inputs, passive	19	Performance characteristics	32
Electrical specification	19	Response time	32
Span	19	Reference temperature	32
Nominal input current	19	Measured error for sensor inputs	32
PFM function	19	Measured error for current inputs and outputs	32
Test voltage	19	Frequency tolerance of digital inputs and outputs	32
Cable specification	19	Resolution of current inputs and outputs	32
Current input, passive	19	Repeatability	32
Span	19	Mounting	33
Signal characteristic	19	Mounting on DIN rail as per IEC 60715	33
Internal resistance	19	Wall mounting	33
Test voltage	19	Mounting the external display	34
Output	20	Environment	34
Output signal	20	Ambient temperature range	34
Signal on alarm	21	Storage temperature	35
Load	21	Humidity	35
Linearization/transmission behavior	21	Degree of protection	35
		Climate class	35
Digital outputs, passive	21	Vibration resistance	35
Electrical specification	21	Electromagnetic compatibility	35

Electrical safety	36
Degree of contamination	36
Mechanical construction	36
Dimensions	36
Weight	39
Materials	39
Operability	40
External display	40
Operating concept	40
Local operation via external, optional display	40
Remote operation	41
Language packages	42
Certificates and approvals	43
CE mark	43
cCSAus	43
cETLus NI Cl. I, Div. 2	43
Ordering information	43
Product page	43
Product Configurator	43
Scope of delivery	43
Accessories	44
Measuring cable	44
Sensors	44
Additional functionality	48
Software	49
Other accessories	50

Function and system design


Measuring system

The overview shows examples of measuring systems. Other sensors and assemblies can be ordered for conditions specific to your application (www.endress.com/products).

Measuring point

A complete measuring system comprises:

- Liquiline transmitter
- Optional display
- Sensors with Memosens technology
- Assemblies to suit the sensors used




1 Cabinet installation (without sensor and signal cables)

- 1 Optional display (back)
- 2 Liquiline
- 3 External power unit (CM444R and CM448R only)
- 4 Power supply cable (to be provided by the customer)
- 5 Display cable

pH value or ORP

pH measurement in drinking water (→ Fig.)

- Retractable assembly Cleanfit CPA871
- Sensor Orbisint CPS11D
- Measuring cable CYK10



ORP in drinking water

- Immersion assembly Dipfit CYA112
- Sensor Orbisint CPS12D
- Measuring cable CYK10


Conductivity

Inductive conductivity measurement in wastewater treatment

- Sensor Indumax CLS50D
- Sensor fixed cable

Conductive conductivity measurement in power plant cooling water


- Sensor Condumax CLS15D
- Measuring cable CYK10



Oxygen

Oxygen in aeration basins

- Immersion assembly Dipfit CYA112
- Holder CYH112
- Sensor
 - COS61D (optical) with fixed cable (→ Fig.)
 - COS51D (amperometric), cable CYK10




Nitrate and SAC

Nitrate in wastewater

- Sensor CAS51D-**A2 with fixed cable
- Immersion assembly CYA112
- Holder CYH112

SAC in the wastewater treatment outlet

- Sensor CAS51D-**2C2 with fixed cable
- Immersion assembly CYA112
- Holder CYH112




Turbidity and interface

Turbidity in industrial water

- Sensor Turbimax CUS51D with fixed cable (→ Fig.)
- Assembly Flowfit CUA250
- Spray head CUR3 (optional)

Interface in the primary clarifier


- Sensor Turbimax CUS71D
- Assembly CYA112
- Holder CYH112



Chlorine

Chlorine (and pH) in drinking water


- Sensor CCS142D
- Sensor CPS11D
- Measuring cable CYK10
- Flow assembly CCA250



Ion-selective electrodes


Ammonium and nitrate measurement in the aeration basin

- Sensor CAS40D with fixed cable
- Holder CYH112



Application example

- Transmitter CM444R-AAM44A0FM6 with:
4 x Memosens, Modbus TCP, 2 digital inputs and 2 digital outputs, 2 x relays for cleaning/limit value, 2 x analog current input
- pH and temperature with CPS11D, item 1 (www.endress.com/cps11d)
- Chlorine with CCS142D, item 4 (www.endress.com/ccs142d)
- 2 x conductivity, inductive measurement with CLS50D, item 2 and 3 (www.endress.com/cls50d)
- 1 x measuring range switching for conductivity via Modbus module
- Flow assembly CCA250 with optional proximity switch INS (www.endress.com/cca250)
- Chlorine regulation with dosing interrupted if no flow: proximity switch via digital input of DIO module, flow feedforward control (via digital or analog input), PFM-controlled dosing pump via digital output of DIO module




2 Measuring point in the CIP process

Data retention

- Storage of all measured values, incl. values of external sources, in the non-volatile memory (data logbook)
- Data called up on site via user-defined measuring menu and load curve display of the data logbook
- Transmission of data by ethernet, CDI interface or SD card and storage in a tamper-proof database (Field Data Manager)
- Data export to csv file (for Microsoft Excel)

Device architecture

Slot and port assignment



3 Slot and port assignment of the hardware modules

Outlet 1			OK
CH1:	1:1 pH Glass	ATC 6.95 pH	Port Slot
CH2:	1:2 TU/TS	500.0 g/l	
CH3:	5:1 SAC	500.0 1/m	
CH4:	5:2 Cond i	ATC 2.62 mS/cm	
CH5:	6:1 Chlorine	28.33 mg/l	
CH6:	6:2 Redox	± 51 mV	
CH7:	7:1 Oxygen (am...	32.86 mg/l	
CH8:	7:2 Cond c	ATC 131.1 µS/cm	
MENU CAL DIAG HOLD			

4 Slot and port assignment on the display

- Inputs are assigned to measuring channels in the ascending order of the slots and ports. Adjacent example: "CH1: 1:1 pH glass" means: Channel 1 (CH1) is slot 1 (basic module) : Port 1 (input 1), pH glass sensor
- Outputs and relays are named according to their function, e.g. "current output", and are displayed with the slot and port numbers in ascending order

Order of the modules

Depending on the version ordered, the device is supplied with a number of electronic modules, which are assigned in a specific sequence in ascending order to slots 0 to 7. If you do not have a particular module, the next moves up automatically:

- The basic module (which is always present) always occupies slots 0 and 1
- Fieldbus module 485 or Ethernet module ETH (only one of the two modules can be used)
- Memosens input module 2DS (DS = digital sensor)
- Extension module for digital inputs and outputs DIO (DIO = digital input and output)
- Current input module 2AI (AI = analog input)
- Current output module 4AO or 2AO (AO = analog output)
- Relay modules AOR, 4R or 2R (AOR = analog output + relay, R = relay)

i Modules with 4 ports are connected before modules of the same type with 2 ports.

Basic rule for hardware upgrades

- Please note the following if upgrading the device:**
 - The sum of all current inputs and outputs may not exceed 8!
 - A maximum of two "DIO" modules may be used.

Determining the hardware delivery status


You must be aware of the type of modules and the number of them supplied with the device you have ordered to determine the delivery status of your Liquiline.

- Basic module
One basic module in all versions. Always occupies slots 0 and 1.
- Fieldbus module
Optional, and only one fieldbus module is possible.
- Input modules
 - Must be clearly assigned to the number of optional inputs ordered.
 - Examples:
 - 2 current inputs = module 2AI
 - 4 Memosens inputs = 2 inputs with basic module + module 2DS with 2 further inputs
- Current outputs and relays
Various module combinations can exist.
The following table will help you determine which modules your device has, depending on the type and number of outputs.

Current outputs	Relays		
	0	2	4
2	-	1 x 2R	1 x 4R
4	1 x 2AO	1 x AOR	1 x 2AO + 1 x 4R
6	1 x 4AO	1 x 4AO + 1 x 2R	1 x 4AO + 1 x 4R
8	1 x 4AO + 1 x 2AO	1 x 4AO + 1 x 2AO + 1 x 2R	1 x 4AO + 1x 2AO + 1 x 4R


- Sum up the number of modules and sort them according to the specified sequence → 6.
 - ↳ This will give you the slot assignment for your device.


Terminal diagram

 The unique terminal name is derived from:
Slot no. : Port no. : Terminal


Example, NO contact of a relay
Device with 4 inputs for digital sensors, 4 current outputs and 4 relays

- Basic module BASE-E (contains 2 sensor inputs, 2 current outputs)
- Module 2DS (2 sensor inputs)
- Module 2AO (2 current outputs)
- Module 4R (4 relays)



 5 Creating a terminal diagram using the example of the NO contact (terminal 41) of a relay


Device configuration using
the example of a CM442R-
**M1A1F0*



A0025348

Ordered basic device (example)	<ul style="list-style-type: none"> Order code CM442R-**M1A1F0* Functionality: 1 x Memosens, 2 current outputs without HART
Extension options without additional modules	<ul style="list-style-type: none"> Second Memosens input (71114663) HART with activation code (71128428)
Extension options by using an extension module in free slot 2	<ul style="list-style-type: none"> Ethernet/PROFIBUS DP/Modbus with module 485 incl. activation code for the desired communication protocol: <ul style="list-style-type: none"> PROFIBUS DP (71140888) Modbus RS485 (71140889) Modbus TCP (71140890) EtherNet/IP (71219868) Only Ethernet without fieldbus (71135634) If fieldbus communication is subsequently required, an activation code is needed for this. Alternative for Ethernet or Modbus TCP: module ETH <p>i If you retrofit module 485, any existing current outputs are disabled! Alternative: ETH (Ethernet, Modbus TCP only).</p> <p>Additional inputs or outputs, relays:</p> <ul style="list-style-type: none"> Module 2AI (71135639): 2 current inputs Module 2AO (71135632): 2 current outputs Module AOR (71111053): 2 current outputs, 2 relays Module 2R (71125375) or 4R (71125376): 2 or 4 relays Module DIO (71135638): 2 digital inputs and 2 digital outputs
Basic rule for extensions	The sum of all current inputs and outputs may not exceed 8!
Restrictions if using CUS71D sensors for interface measurement	Only one CUS71D can be connected. The second Memosens input may not be used.
Product Configurator	www.endress.com/cm442r

Function diagram CM442R




6 Block circuit diagram CM442R


- 1 Current output 1:1, + HART (optional)
- 2 Current outputs (2 x optional)
- 3 2 x Memosens input (1 x optional)
- 4 PROFIBUS DP/Modbus/Ethernet (optional)
- 5 2 x current input (optional)

- 6 Power connection
- 7 Service interface
- 8 Power supply, fixed cable sensors
- 9 Alarm relay
- 10 2 or 4 x relays (optional)
- 11 2 digital inputs and outputs (optional)

Device configuration using
the example of a CM444R-
**M42A1FA*

	
Ordered basic device (example)	<ul style="list-style-type: none"> Order code CM444R-**M42A1FA* Functionality: <ul style="list-style-type: none"> 4 x Memosens (2 on BASE-E module + 2 on an extension module 2DS) PROFIBUS communication (module 485) 2 current outputs without HART (on BASE-E module) 2 current inputs (module 2AI) <p>3 slots are still free in this example. More or fewer slots can be free in other versions.</p>
Extension options without additional modules	None
Modification options without additional modules	<ul style="list-style-type: none"> Communication type changed by entering activation code. This disables the communication type used previously! <ul style="list-style-type: none"> Modbus RS485 (71140889) Modbus TCP (71140890) EtherNet/IP (71219868) Retrofit to HART by removing module 485 and entering activation code for HART (71128428)
Extension options by using extension modules in free slots 5-7	<p>Only the following is possible for the example above: Module 2R (71125375) or 4R (71125376): 2 or 4 relays</p> <p>If extending to eight measuring channels:</p> <ul style="list-style-type: none"> Module 2DS (71135631): 2 Memosens inputs Use of the 2 current outputs in the basic module by entering activation code (71140891) <p>Additional inputs or outputs and relays if fieldbus module 485 is removed:</p> <ul style="list-style-type: none"> Module 2AO (71135632): 2 current outputs Module AOR (71111053): 2 current outputs, 2 relays Module 2R (71125375) or 4R (71125376): 2 or 4 relays Module DIO (71135638): 2 digital inputs and 2 digital outputs <p>i If you replace module 485 with ETH, you can operate up to 6 current outputs in addition to the ETH module's ethernet or Modbus function. Only two current outputs are possible with 485.</p>
Basic rule for extensions	The sum of all current inputs and outputs may not exceed 8!
Restrictions if using CUS71D sensors for interface measurement	<ul style="list-style-type: none"> With the CM444R, any combination of maximum 4 Memosens sensors is possible. An extension to CM448R is not advisable as the maximum number of Memosens inputs remains limited to 4 if a CUS71D is used.
Product Configurator	www.endress.com/cm444r



Function diagram CM444R




7 Block circuit diagram CM444R

- | | | | |
|---|--|----|---|
| 1 | Current output 1:1, + HART (both optional) | 6 | Power connection |
| 2 | Max. 7 x current output (optional) | 7 | Service interface |
| 3 | Memosens input (2 x standard + 2 x optional) | 8 | Power supply, fixed cable sensors |
| 4 | PROFIBUS DP/Modbus/Ethernet (optional) | 9 | Alarm relay |
| 5 | 2 x current input (optional) | 10 | 2 or 4 x relays (optional) |
| | | 11 | 2 digital inputs and outputs (optional) |

Device configuration using
the example of a CM448R-
**26A1*

	
Ordered basic device (example)	<ul style="list-style-type: none"> Order code CM448R-**26A1* Functionality: <ul style="list-style-type: none"> 6 x Memosens (2 on BASE-E module + 2 on two extension modules 2DS) PROFIBUS communication (module 485) <p>3 slots are still free in this example. More or fewer slots can be free in other versions.</p>
Extension options without additional modules	None
Modification options without additional modules	<ul style="list-style-type: none"> Communication type changed by entering activation code. This disables the communication type used previously! <ul style="list-style-type: none"> Modbus RS485 (71140889) Modbus TCP (71140890) EtherNet/IP (71219868) Retrofit to HART by removing module 485 and entering activation code for HART (71128428)
Extension options by using extension modules in free slots 5-7	<p>Only the following is possible for the example above: Module 2R (71125375) or 4R (71125376): 2 or 4 relays</p> <p>If extending to eight measuring channels:</p> <ul style="list-style-type: none"> Module 2DS (71135631): 2 Memosens inputs Use of the 2 current outputs in the basic module by entering activation code (71140891) <p>Additional inputs or outputs, relays:</p> <ul style="list-style-type: none"> Module 2AO (71135632): 2 current outputs Module AOR (71111053): 2 current outputs, 2 relays Module 2R (71125375) or 4R (71125376): 2 or 4 relays Module DIO (71135638): 2 digital inputs and 2 digital outputs <p> If you replace module 485 with ETH, you can operate up to 6 current outputs in addition to the ETH module's ethernet or Modbus function. Only two current outputs are possible with 485.</p>
Basic rule for extensions	The sum of all current inputs and outputs may not exceed 8!
Restrictions if using CUS71D sensors for interface measurement	The maximum number of Memosens inputs that can be used is limited to 4! Here, every combination of CUS71D and other Memosens sensors is then possible.
Product Configurator	www.endress.com/cm448r

Function diagram CM448R



 8 *Block circuit diagram CM448R*

- | | | | |
|---|---|----|---|
| 1 | Current output 1:1, + HART (both optional) | 7 | Service interface |
| 2 | Max. 7 x current output (optional) | 8 | Power supply, fixed cable sensors |
| 3 | Max. 8 x Memosens input (of which 2 x optional) | 9 | Alarm relay |
| 4 | PROFIBUS DP/Modbus/Ethernet (optional) | 10 | 2 or 4 x relays (optional) |
| 6 | Power connection | 11 | 2 digital inputs and outputs (optional) |

Communication and data processing

Types of communication:

- Fieldbuses
 - HART
 - PROFIBUS DP (Profile 3.02)
 - Modbus TCP or RS485
- Configuration via Ethernet
- EtherNet/IP

 Only one type of Fieldbus communication can ever be active. The last activation code entered decides which bus is used.

The device drivers available make it possible to perform a basic setup and display measured values and diagnostics information via the fieldbus. A full device configuration via the fieldbus is not possible.

Extension module 485 and current outputs

For communication types PROFIBUS DP, Modbus and Ethernet:

- CM442R
 - Current outputs cannot be used in parallel. Any existing current outputs are deactivated with the installation of 485.
- CM444R/CM448R
 - Max. of 2 current outputs can be used in parallel.

Extension module ETH and current outputs

- Communication via Ethernet or EtherNet/IP
- CM442R
 - Max. of 2 current outputs can be used in parallel.
- CM444R and CM448R
 - Max. of 6 current outputs can be used in parallel.

Bus termination on the device

- Via slide switch at bus module 485
- Displayed via LED "T" on bus module 485

Dependability

Reliability

Memosens

Memosens makes your measuring point safer and more reliable:

- Non-contact, digital signal transmission enables optimum galvanic isolation
- No contact corrosion
- Completely watertight
- Laboratory sensor calibration possible, thus increasing measured value availability
- Intrinsically safe electronics mean operation in hazardous areas is not a problem.
- Predictive maintenance thanks to recording of sensor data, e.g.:
 - Total hours of operation
 - Hours of operation with very high or very low measured values
 - Hours of operation at high temperatures
 - Number of steam sterilizations
 - Sensor condition

Sensor Check System (SCS)

The Sensor Check System (SCS) monitors the high impedance of the pH glass. An alarm is issued if a minimum impedance value is undershot or a maximum impedance is exceeded.

- Glass breakage is the main reason for a drop in high impedance values
- The reasons for increasing impedance values include:
 - Dry sensor
 - Worn pH glass membrane

 For the SCS, upper and lower limit values can be enabled or disabled independently of one another.

Process Check System (PCS)

The process check system (PCS) checks the measuring signal for stagnation. An alarm is triggered if the measuring signal does not change over a specific period (several measured values).

The main causes of stagnating measured values are:

- Contaminated sensor, or sensor outside of medium
- Sensor defective
- Process error (e.g. through control system)

Sensor Condition Check (SCC)

This function monitors the condition of the electrode and the degree of electrode aging. The status is indicated by the messages "SCC bad" or "SCC sufficient". The condition of the electrode is updated after every calibration.

Self-monitoring functions

Current inputs are deactivated in the event of overcurrent and reactivated once the overcurrent stops. Board voltages are monitored and the board temperature is also measured.

USP and EP

The limit functions for pharmaceutical water in accordance with USP and EP specifications are implemented in the software for conductivity measurements:

- "Water for Injection" (WFI) as per USP <645> and EP
- "Highly Purified Water" (HPW) as per EP
- "Purified Water" (PW) as per EP

The uncompensated conductivity value and the temperature are measured for the USP/EP limit functions. The measured values are compared against the tables defined in the standards. An alarm is triggered if the limit value is exceeded. Furthermore, it is also possible to configure an early warning alarm that signals undesired operating states before they occur.

ChemocleanPlus

Freely programmable sequence control


- e.g. for automatic sensor cleaning in retractable assemblies for reliable measurement results in processes with a high risk of contamination
- Individual, time-based activation of 4 outputs e.g. relays
- Starting, stopping or pausing of activities via digital input or fieldbus signals e.g. from limit position switches

Maintainability


Modular design

The modular transmitter design means it can be easily adapted to suit your needs:

- Retrofit extension modules for new or extended range of functions, e.g. current outputs, relays and digital communication
- Upgrade to maximum of eight-channel measurement
- Optional: M12 sensor connector for connecting any kind of Memosens sensor
- Optional: CDI connector for external access to the service interface (avoids having to unscrew the housing cover)




9 CM444R: example



10 Extension module

Data logger function

- Adjustable scan time: 1 to 3600 s (1 h)
- Data logbooks:
 - Max. 8 data logbooks
 - 150,000 entries per logbook
 - Graphic display (load curves) or numerical list
- Calibration logbook: max. 75 entries
- Hardware version logbook:
 - Hardware configuration and modifications
 - Max. 125 entries
- Version logbook:
 - E.g. software updates
 - Max. 50 entries
- Operation logbook: max. 250 entries
- Diagnostics logbook: max. 250 entries



A0015032

Fig. 11 Data logbook: Graphic display



Logbooks remain unchanged even after a software update.

SD card

The exchangeable storage medium enables:

- Quick and easy software updates and upgrades
- Data storage of internal device memory (e.g. logbooks)
- Transfer of complete configurations to a device with an identical setup (backup function)
- Transfer of configurations without the TAG and bus address to devices with an identical setup (copy function)
- Saving of screenshots for documentation purposes

Endress+Hauser offers industry-approved SD cards as accessories. These memory cards provide maximum data security and integrity.

Other SD cards can also be used. However, Endress+Hauser does not accept any responsibility for the data security of such cards.

External signals for device control and for activating external devices

Hardware options, e.g. module "DIO" with 2 digital inputs and 2 digital outputs or fieldbus module "485" enable the following:

- via a digital input signal
 - measuring range switching for conductivity (upgrade code required, see accessories)
 - switching between different calibration datasets in the case of optical sensors
 - an external hold
 - a cleaning interval to be triggered
 - switching on and off a PID controller, e.g. via the proximity switch of the CCA250
 - the use of the input as an "analog input" for pulse-frequency modulation (PFM)
- via a digital output signal
 - the static transmission (similar to a relay) of diagnostic states, point level switch states etc.
 - the dynamic transmission (comparable to a non-wearing "analog output") of PFM signals, e.g. to control dosing pumps.

FieldCare and Field Data Manager

FieldCare


Configuration and asset management software based on FDT/DTM technology

- Complete device configuration when connected via FXA291 and service interface
- Access to a number of configuration parameters and identification, measuring and diagnostic data when connected via HART modem
- Logbooks can be downloaded in CSV format or binary format for "Field Data Manager" software

Field Data Manager

Visualization software and database for measuring, calibration and configuration data

- SQL database which is protected against manipulation
- Functions to import, save and print out logbooks
- Load curves to display measured values



12 Field Data Manager: Load curves

Virtual process values (mathematical functions)

In addition to "real" process values, which are provided by connected physical sensors or analog inputs, mathematical functions can be used to calculate a maximum of 6 "virtual" process values.

The "virtual" process values can be:

- Output via a current output or a Fieldbus
- Used as a regulating control variable
- Assigned as a measured variable to a limit contactor
- Used as a measured variable to trigger cleaning
- Displayed in user-defined measuring menus.

The following mathematical functions are possible:

- pH calculation based on two conductivity values acc. to VGB 405 RL, e.g. in boiler feed water
- Difference between two measured values from different sources, e.g. for membrane monitoring
- Differential conductivity, e.g. monitoring the efficiency of ion exchangers
- Degassed conductivity, e.g. for process controls in power plants
- Redundancy for monitoring two or three redundantly measuring sensors
- rH calculation based on the measured values of a pH and an ORP sensor

Concentration tables

When the device is delivered from the factory, tables are saved in the device that allow inductive conductivity measurements to be converted to concentrations of certain substances. 4 user-defined tables are also possible.

The following factory concentration tables are available:

NaOH	0 ... 15 %	0 to 100 °C (32 to 212 °F)
NaOH	25 ... 50%	2 to 80 °C (36 to 176 °F)
HCl	0 to 20 %	0 to 65 °C (32 to 149 °F)
HNO ₃	0 to 30 %	2 to 80 °C (36 to 176 °F)
H ₂ SO ₄	0 to 28 % and 35 to 85 %	0 to 100 °C (32 to 212 °F)
H ₂ SO ₄	93 to 100 %	0 to 100 °C (32 to 212 °F)
H ₃ PO ₄	0 ... 40 %	2 to 80 °C (36 to 176 °F)
NaCl	0 ... 26 %	2 to 80 °C (36 to 176 °F)

Safety

Real-time clock

The device has a real-time clock, which is buffered by a button cell battery if the power supply fails.

This ensures that the device continues to keep the correct date and time when it is restarted and that the time stamp for the logbooks is correct.

Data security

All settings, logbooks etc. are stored in a non-volatile memory to ensure that the data are retained even in the event of a disruption to the power supply.

Measuring range switching for conductivity

- Can be used in CIP processes e.g. for safe monitoring of phase separations
- Switching between 4 complete parameter sets:
 - Conductivity operating mode
 - Concentration tables
 - Temperature compensation
 - Output signal range
 - Limit value switch
- Via digital inputs or fieldbus

Measured value compensation for oxygen and conductivity

- Pressure or temperature compensation
- Input signals from external sensors via current input or fieldbus
- Signals from connected temperature sensors

Password protection

Password-protected login

- For remote operation via web server
- For local operation

Process safety

Two independent PID controllers

- One- or two-sided control
- Limit switches
- 4 cleaning programs which can be programmed independently of each other

IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

Input

Measured variables	→ Documentation of the connected sensor
Measuring ranges	→ Documentation of the connected sensor
Types of input	<ul style="list-style-type: none"> ■ Digital sensor inputs for sensors with Memosens protocol ■ Analog current inputs (optional) ■ Digital inputs (optional)
Input signal	Depending on version <ul style="list-style-type: none"> ■ Max. 8 x binary sensor signal ■ 2 x 0/4 to 20 mA (optional), passive, potentially isolated from one another and from the sensor inputs ■ 0 to 30 V
Cable specification	Cable type Memosens data cable CYK10 or sensor fixed cable, each with cable end sleeves or M12 round-pin connector (optional) Cable length Max. 100 m (330 ft)

Digital inputs, passive

Electrical specification	<ul style="list-style-type: none"> ■ drawing power (passive) ■ Galvanically isolated
Span	High: 11 to 30 V DC Low: 0 to 5 V DC
Nominal input current	Max. 8 mA
PFM function	Minimum pulse width: 500 µs (1 kHz)
Test voltage	500 V
Cable specification	Max. 2.5 mm ² (14 AWG)

Current input, passive

Span	> 0 to 20 mA
Signal characteristic	Linear
Internal resistance	Non-linear
Test voltage	500 V

Output

Output signal

Depending on version:

- 2 x 0/4 to 20 mA, active, potentially isolated from one another and from the sensor circuits
- 4 x 0/4 to 20 mA, active, potentially isolated from one another and from the sensor circuits
- 6 x 0/4 to 20 mA, active, potentially isolated from one another and from the sensor circuits
- 8 x 0/4 to 20 mA, active, potentially isolated from one another and from the sensor circuits
- Optional HART communication (only via current output 1:1)

HART	
Signal encoding	FSK \pm 0.5 mA above current signal
Data transmission rate	1200 baud
Galvanic isolation	Yes
Load (communication resistor)	250 Ω

PROFIBUS DP/RS485	
Signal encoding	EIA/TIA-485, PROFIBUS DP-compliant acc. to IEC 61158
Data transmission rate	9.6 kBd, 19.2 kBd, 45.45kBd, 93.75 kBd, 187.5 kBd, 500 kBd, 1.5 MBd, 6 MBd, 12 MBd
Galvanic isolation	Yes
Connectors	Spring terminal (max. 1.5 mm), bridged internally in the connector (T-function), M12 optional
Bus termination	Internal slide switch with LED display

Modbus RS485	
Signal encoding	EIA/TIA-485
Data transmission rate	2,400, 4,800, 9,600, 19,200, 38,400, 57,600 and 115,200 baud
Galvanic isolation	Yes
Connectors	Spring terminal (max. 1.5 mm), bridged internally in the connector (T-function), M12 optional
Bus termination	Internal slide switch with LED display

Ethernet and Modbus TCP	
Signal encoding	IEEE 802.3 (Ethernet)
Data transmission rate	10/100 MBd
Galvanic isolation	Yes
Connection	RJ45
IP address	DHCP (default) or configuration via menu

EtherNet/IP	
Signal encoding	IEEE 802.3 (Ethernet)
Data transmission rate	10/100 MBd
Galvanic isolation	Yes
Connection	RJ45
IP address	DHCP (default) or configuration via menu

Signal on alarm	Adjustable, as per NAMUR Recommendation NE 43 <ul style="list-style-type: none"> ■ In measuring range 0 to 20 mA (HART is not available with this measuring range): Error current from 0 to 23 mA ■ In measuring range 4 to 20 mA: Error current from 2.4 to 23 mA ■ Factory setting for error current for both measuring ranges: 21,5 mA
------------------------	--

Load	Max. 500 Ω
-------------	-------------------

Linearization/transmission behavior	Linear
--	--------

Digital outputs, passive

Electrical specification	<ul style="list-style-type: none"> ■ Passive ■ Open collector, max. 30 V, 15 mA
---------------------------------	---

PFM function	Minimum pulse width: 500 μ s (1 kHz)
---------------------	--

Auxiliary voltage	Electrical specification <ul style="list-style-type: none"> ■ Galvanically isolated ■ Unregulated, 24 V DC \pm 20% ■ Max. 50 mA (per DIO module)
--------------------------	---

Test voltage	500 V
---------------------	-------

Cable specification	Max. 2.5 mm ² (14 AWG)
----------------------------	-----------------------------------

Current outputs, active

Span	0 to 23 mA 2.4 to 23 mA for HART communication
-------------	---

Signal characteristic	Linear
------------------------------	--------

Electrical specification	Output voltage Max. 24 V Test voltage 500 V
---------------------------------	--

Cable specification	Cable type Recommended: shielded cable Cable specification Max. 2.5 mm ² (14 AWG)
----------------------------	---

Relay outputs

Electrical specification

Relay types

- 1 single-pin changeover contact (alarm relay)
- 2 or 4 single-pin changeover contacts (optional with extension modules)

Relay switching capacity

Basic module (Alarm relay)

Switching voltage	Load (max.)	Switching cycles (min.)
230 V AC, $\cos\Phi = 0.8$ to 1	0.1 A	700,000
	0.5 A	450,000
115 V AC, $\cos\Phi = 0.8$ to 1	0.1 A	1,000,000
	0.5 A	650,000
24 V DC, L/R = 0 to 1 ms	0.1 A	500,000
	0.5 A	350,000

Extension modules

Switching voltage	Load (max.)	Switching cycles (min.)
230 V AC, $\cos\Phi = 0.8$ to 1	0.1 A	700,000
	0.5 A	450,000
	2 A	120,000
115 V AC, $\cos\Phi = 0.8$ to 1	0.1 A	1,000,000
	0.5 A	650,000
	2 A	170,000
24 V DC, L/R = 0 to 1 ms	0.1 A	500,000
	0.5 A	350,000
	2 A	150,000

Cable specification

Max. 2.5 mm² (14 AWG)

Protocol-specific data

HART

Manufacturer ID	11 _h
Device type	155D _h
Device revision	001 _h
HART version	7.2
Device description files (DD/DTM)	www.endress.com/hart Device Integration Manager DIM
Device variables	16 user-definable and 16 predefined device variables, dynamic variables PV, SV, TV, QV
Supported features	PDM DD, AMS DD, DTM, Field Xpert DD

PROFIBUS DP	Manufacturer ID	11 _h		
	Device type	155D _h		
	Profile version	3.02		
	GSD files	www.endress.com/profibus Device Integration Manager DIM		
	Output values	16 AI blocks, 8 DI blocks		
	Input variables	4 AO blocks, 8 DO blocks		
	Supported features	<ul style="list-style-type: none">■ 1 MSCY0 connection (cyclical communication, master class 1 to slave)■ 1 MSAC1 connection (acyclical communication, master class 1 to slave)■ 2 MSAC2 connections (acyclical communication, master class 2 to slave)■ Device lock: The device can be locked using the hardware or software.■ Addressing using DIL switches or software■ GSD, PDM DD, DTM		
Modbus RS485	Protocol	RTU/ASCII		
	Function codes	03, 04, 06, 08, 16, 23		
	Broadcast support for function codes	06, 16, 23		
	Output data	16 measured values (value, unit, status), 8 digital values (value, status)		
	Input data	4 setpoints (value, unit, status), 8 digital values (value, status), diagnostic information		
	Supported features	Address can be configured using switch or software		
Modbus TCP	TCP port	502		
	TCP connections	3		
	Protocol	TCP		
	Function codes	03, 04, 06, 08, 16, 23		
	Broadcast support for function codes	06, 16, 23		
	Output data	16 measured values (value, unit, status), 8 digital values (value, status)		
	Input data	4 setpoints (value, unit, status), 8 digital values (value, status), diagnostic information		
	Supported features	Address can be configured using DHCP or software		
EtherNet/IP	Protocol	EtherNet/IP		
	ODVA certification	Yes		
	Device profile	Generic device (product type: 0x2B)		
	Manufacturer ID	0x049E _h		
	Device type ID	0x109C _h		
	Polarity	Auto-MIDI-X		
	Connections	CIP	12	
		I/O	6	
		Explicit message	6	
		Multicast	3 consumers	
	Minimum RPI	100 ms (default)		

Maximum RPI	10000 ms	
System integration	EtherNet/IP	EDS
	Rockwell	Add-on-Profile Level 3, Faceplate for Factory Talk SE
IO data	Input (T → O)	Device status and diagnostic message with highest priority Measured values: <ul style="list-style-type: none"> 16 AI (analog input) + Status + Unit 8 DI (discrete input) + Status
	Output (O → T)	Actuating values: <ul style="list-style-type: none"> 4 AO (analog output) + status + unit 8 DO (discrete output) + Status

Web server

The web server enables full access to the device configuration, measured values, diagnostic messages, logbooks and service data via standard WiFi/WLAN/LAN/GSM or 3G routers with a user-defined IP address.

TCP port	80
Supported features	<ul style="list-style-type: none"> Remote-controlled device configuration(1 session) Save/restore device configuration (via SD card) Logbook export (file formats: CSV, FDM) Access to web server via DTM or Internet Explorer Login Web server can be switched off

Power supply

Supply voltage**CM442R**

Depending on version:

- 100 to 230 V AC $\pm 15\%$, 50/60 Hz
- 24 V AC/DC $+20/-15\%$, 50/60 Hz

CM444R and CM448R

Depending on version via external DIN rail power unit:

- 100 to 230 V AC $\pm 15\%$, 50/60 Hz
- 24 V DC $+20 / -15\%$

NOTICE**The device does not have a power switch**

- The customer must provide a protected circuit breaker in the vicinity of the device.
- The circuit breaker must be a switch or power switch, and you must label it as the circuit breaker for the device.
- At the supply point, the power supply for the 24 V versions must be isolated from dangerous live cables by double or reinforced insulation.

Fieldbus connection

Supply voltage: not applicable

Power consumption**CM442R**

Depending on supply voltage

- 100 to 230 V AC and 24 V AC:
Max. 55 VA
- 24 V DC:
Max. 22 W



CM444R and CM448R

Depending on supply voltage

- 100 to 230 V AC:
Max. 150 VA
- 24 V DC:
Max. 59 W

Fuse	Fuse not exchangeable
Overvoltage protection	Integrated overvoltage/lightning protection as per EN 61326 Protection category 1 and 3
Cable specification for optional display cable	Length of display cable supplied 3 m (10 ft) Maximum permitted length of display cable: 5 m (16.5 ft)

Electrical connection **Basic module**




- 13 Basic module BASE-H or -L (two-channel device)
- 1 Power supply for digital fixed cable sensors with Memosens protocol
 - 2 SD card slot
 - 3 Slot for display cable ¹⁾
 - 4 Service interface
 - 5 Connections for 2 Memosens sensors
 - 6 Current outputs
 - 7 Power connection
 - 8 Alarm relay connection

¹⁾ For optional external display.
²⁾ Power supply to DIN rail power unit.

- 14 Basic module BASE-E (four- and eight-channel device)
- 1 Power supply for digital fixed cable sensors with Memosens protocol
 - 2 SD card slot
 - 3 Slot for display cable ¹⁾
 - 4 Service interface
 - 5 Connections for 2 Memosens sensors
 - 6 Current outputs
 - 7 LEDs
 - 8 Socket for internal supply cable ²⁾
 - 9 Alarm relay connection


Connecting supply voltage for CM442R



15 Connecting power supply on the BASE-H or -L


H Power unit 100 to 230 VAC

L Power unit 24 VAC or 24 VDC



16 Overall wiring diagram for BASE-H or -L

Connecting supply voltage for CM444R and CM448R




17 Connecting power supply with BASE-E

* Assignment depending on power unit, make sure to connect correctly



The two device versions may only be operated with the power unit supplied and the power unit cable. Also pay attention to the information in the operating manual supplied for the power unit.



18 Overall wiring diagram for BASE-E and external power unit (B)

Connecting optional modules











With extension modules you can purchase additional functions for your device.











NOTICE**Unacceptable hardware combinations (due to conflicts in power supply)**

Incorrect measurements or total failure of the measuring point as a result of heat build-up or overloading

- ▶ If you are planning to extend your controller, make sure the resulting hardware combination is permitted (Configurator on www.endress.com/CM442R or .../CM444R or .../CM448R).
- ▶ Remember that the sum of all current inputs and outputs may not exceed 8!
- ▶ Make sure not to use more than two "DIO" modules. More "DIO" modules are not permitted.
- ▶ Please contact your Endress+Hauser sales center should you have any questions.

Overview of all the modules available


Module name				
AOR	2R	4R	2DS	DIO
				
<ul style="list-style-type: none"> ■ 2 x 0/4 to 20mA analog outputs ■ 2 relays ■ Order No. 71111053 	<ul style="list-style-type: none"> ■ 2 relays ■ Order No. 71125375 	<ul style="list-style-type: none"> ■ 4 relays ■ Order No. 71125376 	<ul style="list-style-type: none"> ■ 2 digital sensor inputs ■ 2 power supply systems for digital sensors ■ Order No. 71135631 	<ul style="list-style-type: none"> ■ 2 digital inputs ■ 2 digital outputs with auxiliary voltage ■ Order No. 71135638
				

Module name				
2AO	4AO	2AI	485	ETH
				
<ul style="list-style-type: none">2 x 0/4 to 20mA analog outputsOrder No. 71135632	<ul style="list-style-type: none">4 x 0/4 to 20mA analog outputsOrder No. 71135633	<ul style="list-style-type: none">2 x 0/4 to 20mA analog inputsOrder No. 71135639	<ul style="list-style-type: none">Ethernet (web server or Modbus TCP)5V power supply for PROFIBUS DP terminationRS485 (PROFIBUS DP or Modbus RS485)Order No. 71135634	<ul style="list-style-type: none">Ethernet (web server or Modbus TCP)Order No. 71272410
				

 **PROFIBUS DP (module 485)**

Contacts A - A', B - B' and C - C' are bridged in the connector. This ensures that PROFIBUS communication is not interrupted if the connector is disconnected.

Protective ground connection



19 Mounting rail for functional ground connections

Sensor connection*Sensors with Memosens protocol*


Sensor types	Sensor cable	Sensors
Digital sensors without additional internal power supply	With plug-in connection and inductive signal transmission	<ul style="list-style-type: none"> ■ pH sensors ■ ORP sensors ■ Combined sensors ■ Oxygen sensors (amperometric and optical) ■ Conductive conductivity sensors ■ Chlorine sensors
	fixed cable	Inductive conductivity sensors
Digital sensors with additional internal power supply	fixed cable	<ul style="list-style-type: none"> ■ Turbidity sensors ■ Sensors for interface measurement ■ Sensors for measuring the spectral absorption coefficient (SAC) ■ Nitrate sensors ■ Optical oxygen sensors ■ Ion-sensitive sensors

The following rule applies if connecting CUS71D sensors:


- CM442R
 - Only one CUS71D is possible; an additional sensor is not permitted.
 - The second sensor input may also not be used for another type of sensor.
- CM444R
 - No restrictions. All the sensor inputs can be used as required.
- CM448R
 - If a CUS71D is connected, the number of sensor inputs that can be used is limited to a maximum of 4.
 - Of these, all 4 inputs can be used for CUS71D sensors.
 - Every combination of CUS71D and other sensors is possible, provided that the total number of connected sensors does not exceed 4.

Connection


Sensor cable connected directly to the terminal connector of the sensor module 2DS or of the basic module L, H or E (→  20 ff.)



20 Sensors without additional supply voltage



21 Sensors with additional supply voltage



22 Sensors with and without additional supply voltage at sensor module 2DS

Performance characteristics

Response time	Current outputs t_{90} = max. 500 ms for an increase from 0 to 20 mA Current inputs t_{90} = max. 330 ms for an increase from 0 to 20 mA Digital inputs and outputs t_{90} = max. 330 ms for an increase from low to high
Reference temperature	25 °C (77 °F)
Measured error for sensor inputs	→ Documentation of the connected sensor
Measured error for current inputs and outputs	Typical measured errors: $< 20 \mu\text{A}$ (with current values $< 4 \text{ mA}$) $< 50 \mu\text{A}$ (with current values 4 to 20 mA) at 25 °C (77 °F) each Additional measured error depending on the temperature: $< 1.5 \mu\text{A/K}$
Frequency tolerance of digital inputs and outputs	$\leq 1\%$
Resolution of current inputs and outputs	$< 5 \mu\text{A}$
Repeatability	→ Documentation of the connected sensor

Mounting

Mounting on DIN rail as per IEC 60715

NOTICE


Incorrect mounting location in the cabinet, spacing regulations not observed

Possible malfunctions as a result of heat development and interference from neighboring devices

- ▶ Do not position the device directly above sources of heat. Make sure to observe the temperature specification.
- ▶ The components are designed for convection-based cooling. Avoid the buildup of heat and ensure openings are not covered over, e.g. by cables.
- ▶ Make sure to keep the specified distance to other devices.
- ▶ Physically separate the device from frequency converters and high-voltage devices.
- ▶ Recommended installation direction: horizontal. The specified ambient conditions, and particularly the ambient temperatures, only apply for horizontal installation.
- ▶ Vertical orientation is also possible. However, this requires additional fixing clips at the place of installation to hold the device in position on the DIN rail.
- ▶ Recommended installation of the power unit for CM444R and CM448R: to the left of the device.

The following minimum spacing specifications must be observed:


- Distance at the side to other devices including power units and distance to control cabinet wall: at least 20 mm (0.79 inch)
- Distance above and below the device and depth distance (to control cabinet door or other devices installed there): at least 50 mm (1.97 inch)



A0025369

23 Minimum spacing in mm (inch)

Wall mounting




A0025370

24 Drilling pattern for wall mounting in mm (inch)

Mounting the external display



The mounting plate also serves as the drilling template. The marks on the side help you mark the position of the drill holes.



A0025371

25 Mounting plate of external display in mm (inch)

a Retaining tab

b Production-related recesses, no function for the user

Environment

Ambient temperature range

CM442R

–20 to 60 °C (0 to 140 °F)

CM444R

■ Generally –20 to 55 °C (0 to 130 °F), with the exception of packages under the second point in the list

■ –20 to 50 °C (0 to 120 °F) for the following packages:

- CM444R-**M40A7FI*+...
- CM444R-**M40A7FK*+...
- CM444R-**N40A7FI*+...
- CM444R-**N40A7FK*+...
- CM444R-**M4AA5F4*+...
- CM444R-**M4AA5FF*+...
- CM444R-**M4AA5FH*+...
- CM444R-**M4AA5FI*+...
- CM444R-**M4AA5FK*+...
- CM444R-**M4AA5FM*+...
- CM444R-**M4BA5F4*+...
- CM444R-**M4BA5FF*+...
- CM444R-**M4BA5FH*+...
- CM444R-**M4BA5FI*+...
- CM444R-**M4BA5FK*+...
- CM444R-**M4BA5FM*+...
- CM444R-**M4DA5F4*+...
- CM444R-**M4DA5FF*+...
- CM444R-**M4DA5FH*+...
- CM444R-**M4DA5FI*+...
- CM444R-**M4DA5FK*+...
- CM444R-**M4DA5FM*+...

CM448R

- Generally -20 to 55 °C (0 to 130 °F), with the exception of packages under the second point in the list
- -20 to 50 °C (0 to 120 °F) for the following packages:
 - CM448R-***6AA*+...
 - CM448R-***8A4*+...
 - CM448R-***8A5*+...
 - CM448R-**28A3*+...
 - CM448R-**38A3*+...
 - CM448R-**48A3*+...
 - CM448R-**58A3*+...
 - CM448R-**68A3*+...
 - CM448R-**26A5*+...
 - CM448R-**36A5*+...
 - CM448R-**46A5*+...
 - CM448R-**56A5*+...
 - CM448R-**66A5*+...
 - CM448R-**22A7*+...
 - CM448R-**32A7*+...
 - CM448R-**42A7*+...
 - CM448R-**52A7*+...
 - CM448R-**62A7*+...
 - CM448R-**A6A5*+...
 - CM448R-**A6A7*+...
 - CM448R-**B6A5*+...
 - CM448R-**B6A7*+...
 - CM448R-**C6A5*+...
 - CM448R-**C6A7*+...
 - CM448R-**D6A5*+...
 - CM448R-**D6A7*+...

External display (optional)

-20 to 60 °C (0 to 140 °F)

Storage temperature	-25 to +85 °C (-10 to +185 °F)													
Humidity	DIN rail device 5 to 85%, not condensing External display (in installed state) 5 to 95%, not condensing													
Degree of protection	DIN rail device IP20 shock protection External display IP66 front-panel, when installed correctly and with appropriate protective enclosure													
Climate class	As per IEC 60654-1: B2													
Vibration resistance	Environmental tests Vibration test based on DIN EN 60068-2, October 2008 Vibration test based on DIN EN 60654-3, August 1998 Wall mounting <table><tr><td>Frequency range</td><td colspan="2">10 to 150 Hz (sinusoidal)</td></tr><tr><td rowspan="2">Amplitude</td><td>10 to 12.9 Hz:</td><td>0.75 mm</td></tr><tr><td>12.9 to 150 Hz:</td><td>0.5 g ¹⁾</td></tr><tr><td>Test duration</td><td colspan="2">10 frequency cycles/ spatial axis, in 3 spatial axes (1 oct./min)</td></tr></table> 1) g ... gravitational acceleration (1 g ≈ 9.81 m/s²)			Frequency range	10 to 150 Hz (sinusoidal)		Amplitude	10 to 12.9 Hz:	0.75 mm	12.9 to 150 Hz:	0.5 g ¹⁾	Test duration	10 frequency cycles/ spatial axis, in 3 spatial axes (1 oct./min)	
Frequency range	10 to 150 Hz (sinusoidal)													
Amplitude	10 to 12.9 Hz:	0.75 mm												
	12.9 to 150 Hz:	0.5 g ¹⁾												
Test duration	10 frequency cycles/ spatial axis, in 3 spatial axes (1 oct./min)													
Electromagnetic compatibility	Interference emission and interference immunity as per EN 61326-1:2013, Class A for Industry													


Electrical safety	IEC 61010-1, Class I equipment Low voltage: overvoltage category II Environment < 2000 m (< 6562 ft) above MSL
--------------------------	--

Degree of contamination	DIN rail device The product is suitable for pollution degree 2.
--------------------------------	---

Optional display	The product is suitable for pollution degree 4.
-------------------------	---

Mechanical construction


Dimensions	CM442R
-------------------	---------------



26 Dimensions in mm (inch)

A0025344


CM444R and CM448R



A0025345

27 Dimensions in mm (inch)

Optional display




A0025346

28 Dimensions in mm (inch)


External power units (CM444R and CM448R only)

Depending on the version ordered, a power unit for connection to 230 V or 24 V is supplied. There are two delivery variants for each version (cannot be selected). The factory-preferred variant is shown on the left in each case.




A0025738

29 Power unit 230 V




A0025739

30 Power unit 230 V (optional)



A0025784

31 Power unit 24 V




A0025786

32 Power unit 24 V (optional)

Service display (accessories)

The service display comprises:

- Portable display (same dimensions as under "Optional display")
- Cover to protect the display and to hook it onto the (open) cabinet door



33 Dimensions of the service display cover in mm (inch)

Weight

Depending on version:

CM442R (fully configured)	Approx. 0.45 kg (1 lbs)
CM444R and CM448R (fully configured)	Approx. 0.95 kg (2.1 lbs)
Individual module	Approx. 0.06 kg (0.13 lbs)
External display (excluding cables)	Approx. 0.56 kg (1.2 lbs)
Service display cover	0.46 kg (1 lbs)
External power unit (CM444R, CM448R)	0.27 to 0.42 kg (0.60 to 0.92 lbs), depending on the power unit variant

Materials

DIN rail housing	PC-FR
Display cover	PC-FR
Display seal	EPDM
Soft keys	EPDM
Module covers	PBT GF30 FR
Terminal strip	Nickel-plated brass
Ground terminals	Stainless steel 1.4301 (AISI304)
Threaded fasteners	Stainless steel 1.4301 (AISI304)
Mounting plate (display)	Stainless steel 1.4301 (AISI304)
Securing screws (display)	Steel, galvanized
Cover for service display (accessories)	EPDM

Operability


External display	<p>Graphic display:</p> <ul style="list-style-type: none">■ Resolution: 240 x 160 pixel■ Back light with switch-off function■ Red display background for alarms alerts users to errors■ Transflective display technology for maximum contrast even in bright environments■ User-definable measuring menus mean you can always keep track of the values that are important for your application.
------------------	---

Operating concept	<p>The simple and structured operating concept sets new standards:</p> <ul style="list-style-type: none">■ Intuitive operation with the navigator and soft keys■ Fast configuration of application-specific measurement options■ Easy configuration and diagnosis thanks to plain-text display■ All languages that can be ordered are available in every device
-------------------	--



34 Operation via external, optional display 35 Plain-text menu

Local operation via external, optional display




36 Overview of operation

1 Display (with red display background in alarm condition)
2 Soft keys (function depends on menu)
3 Navigator (jog/shuttle and press/hold function)

Remote operation

Via HART (e.g. using HART modem and FieldCare)




A0024450

37 HART using modem

- 1 Device module Base L, H or E: current output 1 with HART
 - 2 HART modem to connect to PC, e.g. Commubox FXA191 (RS232) or FXA195 ¹⁾ (USB)
 - 3 HART handheld terminal
- ¹⁾ Switch position "on" (substitutes the resistor)


Via PROFIBUS DP



A0024451

38 PROFIBUS DP


T Terminating resistor

Via Modbus RS485

A0024454

39 Modbus RS485

T Terminating resistor

Via Ethernet/Web server/Modbus TCP/EtherNet/IP

A0024455

40 Modbus TCP and/or EtherNet/IP

Language packages

The language selected in the product structure is the operating language preset at the factory. All other languages can be selected using the menu.

- English (US)
- German
- Chinese (Simplified, PR China)
- Czech
- Dutch
- French
- Italian
- Japanese
- Polish
- Portuguese
- Russian
- Spanish
- Swedish

- Turkish
- Hungarian
- Croatian
- Vietnamese

The availability of other languages can be seen in the product structure at www.endress.com/CM442R or [.../CM444R](http://www.endress.com/CM444R) or [.../CM448R](http://www.endress.com/CM448R).

Certificates and approvals

CE mark	The product meets the requirements of the harmonized European standards. As such, it complies with the legal specifications of the EC directives. The manufacturer confirms successful testing of the product by affixing to it the CE mark.
cCSAus	The product complies with "CLASS 2252 05 - Process Control Equipment" and "CLASS 2252 85 - Process Control Equipment - Certified to US Standards" requirements.
cETLus NI Cl. I, Div. 2	<p>Only CM444R and CM448R</p> <ul style="list-style-type: none"> ■ Complies with UL STD 61010-1, ANSI/ISA STD 12.12.01, FM STD 3600 and FM STD 3611 ■ Certified according to CSA STD C22.2 NO. 61010-1 and CSA STD C22.2 NO. 213 ■ ETL control number: 5000765 <p>► The device must be installed in a housing or cabinet where access is only possible with a tool or key.</p>

Ordering information

Product page	www.endress.com/cm442r www.endress.com/cm444r www.endress.com/cm448r
Product Configurator	<p>The navigation area is located on the right of the product page.</p> <ol style="list-style-type: none"> 1. Under "Device support" click "Configure your selected product". <ul style="list-style-type: none"> ↳ The Configurator opens in a separate window. 2. Select all the options to configure the device in line with your requirements. <ul style="list-style-type: none"> ↳ In this way, you receive a valid and complete order code for the device. 3. Export the order code as a PDF or Excel file. To do so, click the appropriate button at the top of the screen.
Scope of delivery	<p>The scope of delivery comprises:</p> <ul style="list-style-type: none"> ■ 1 controller in the version ordered ■ 1 mounting plate ■ 1 external display (optional) ■ 1 DIN rail power unit incl. cable (CM444R and CM448R only) ■ 1 printed copy of the operating manual for the DIN rail power unit ■ 1 printed copy of the Brief Operating Instructions in the language ordered

Accessories



The following are the most important accessories available at the time this documentation was issued. For accessories not listed here, please contact your service or sales office.

Measuring cable

CYK10 Memosens data cable

- For digital sensors with Memosens technology
- Product Configurator on the product page: www.endress.com/cyk10



Technical Information TI00118C

Memosens data cable CYK11

- Extension cable for digital sensors with Memosens protocol
- Product Configurator on the product page: www.endress.com/cyk11



Technical Information TI00118C

Sensors

Glass electrodes

Orbisint CPS11D

- pH electrode for process technology
- Optional SIL version for connecting to SIL transmitter
- With dirt-repellent PTFE diaphragm
- Product Configurator on the product page: www.endress.com/cps11d



Technical Information TI00028C

Memosens CPS31D

- pH electrode with gel-filled reference system with ceramic diaphragm
- Product Configurator on the product page: www.endress.com/cps31d



Technical Information TI00030C

Ceraliquid CPS41D

- pH electrode with ceramic junction and KCl liquid electrolyte
- Product Configurator on the product page: www.endress.com/cps41d



Technical Information TI00079C

Ceragel CPS71D

- pH electrode with double-chamber reference system and integrated bridge electrolyte
- Product Configurator on the product page: www.endress.com/cps71d



Technical Information TI00245C

Orbipore CPS91D

- pH electrode with open aperture diaphragm for media with high dirt load
- Product Configurator on the product page: www.endress.com/cps91d



Technical Information TI00375C

Orbipac CPF81D

- Compact pH sensor for installation or immersion operation
- In industrial water and wastewater
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cpf81d



Technical Information TI00191C

Enamel pH electrodes

Ceramax CPS341D

- pH electrode with pH-sensitive enamel
- Meets highest demands of measuring accuracy, pressure, temperature, sterility and durability
- Product Configurator on the product page: www.endress.com/cps341d



Technical Information TI00468C

ORP sensors

Orbisint CPS12D

- ORP sensor for process technology
- Product Configurator on the product page: www.endress.com/cps12d

 Technical Information TI00367C

Ceraliquid CPS42D

- ORP electrode with ceramic junction and KCl liquid electrolyte
- Product Configurator on the product page: www.endress.com/cps42d

 Technical Information TI00373C

Ceragel CPS72D

- ORP electrode with double-chamber reference system and integrated bridge electrolyte
- Product Configurator on the product page: www.endress.com/cps72d

 Technical Information TI00374C


Orbipac CPF82D

- Compact ORP sensor for installation or immersion operation in process water and wastewater
- Product Configurator on the product page: www.endress.com/cpf82d

 Technical Information TI00191C

Orbipore CPS92D

- ORP electrode with open aperture diaphragm for media with high dirt load
- Product Configurator on the product page: www.endress.com/cps92d

 Technical Information TI00435C

pH ISFET sensors


Tophit CPS441D

- Sterilizable ISFET sensor for low-conductivity media
- Liquid KCl electrolyte
- Product Configurator on the product page: www.endress.com/cps441d

 Technical Information TI00352C

Tophit CPS471D

- Sterilizable and autoclavable ISFET sensor for food and pharmaceuticals, process engineering
- Water treatment and biotechnology
- Product Configurator on the product page: www.endress.com/cps471d

 Technical Information TI00283C

Tophit CPS491D

- ISFET sensor with open aperture diaphragm for media with high dirt load
- Product Configurator on the product page: www.endress.com/cps491d

 Technical Information TI00377C

pH and ORP combined sensors

Memosens CPS16D

- Combined pH/ORP sensor for process technology
- With dirt-repellent PTFE diaphragm
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cps16d

 Technical Information TI00503C

Memosens CPS76D

- Combined pH/ORP sensor for process technology
- Hygienic and sterile applications
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cps76d



Technical Information TI00506C

Memosens CPS96D

- Combined pH/ORP sensor for chemical processes
- With poison-resistant reference with ion trap
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cps96d



Technical Information TI00507C

Conductivity sensors with inductive measurement of conductivity**Indumax CLS50D**

- High-durability inductive conductivity sensor
- For standard, hazardous and high-temperature applications
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cls50d



Technical Information TI00182C

Indumax H CLS54D

- Inductive conductivity sensor
- With certified, hygienic design for foodstuffs, beverages, pharmaceuticals and biotechnology
- Product Configurator on the product page: www.endress.com/cls54d



Technical Information TI00508C

Conductivity sensors with conductive measurement of conductivity**Condumax CLS15D**

- Conductive conductivity sensor
- For pure water applications, ultrapure water applications and Ex applications
- Product Configurator on the product page: www.endress.com/CLS15d



Technical Information TI00109C

Condumax CLS16D

- Hygienic, conductive conductivity sensor
- For pure water applications, ultrapure water applications and Ex applications
- With EHEDG and 3A approval
- Product Configurator on the product page: www.endress.com/CLS16d



Technical Information TI00227C

Condumax CLS21D

- Two-electrode sensor in plug-in head version
- Product Configurator on the product page: www.endress.com/CLS21d



Technical Information TI00085C

Memosens CLS82D

- Four-electrode sensor
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cls82d




Technical Information TI01188C

Oxygen sensors

Oxymax COS22D

- Sterilizable sensor for dissolved oxygen
- With Memosens technology or as an analog sensor
- Product Configurator on the product page: www.endress.com/cos22d

 Technical Information TI00446C

Oxymax COS51D

- Amperometric sensor for dissolved oxygen
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cos51d

 Technical Information TI00413C

Oxymax COS61D

- Optical oxygen sensor for drinking water and industrial water measurement
- Measuring principle: quenching
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cos61d

 Technical Information TI00387C

Memosens COS81D

- Sterilizable, optical sensor for dissolved oxygen
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cos81d

 Technical Information TI01201C

Chlorine sensors

CCS142D

- Membrane-covered amperometric sensor for free chlorine
- Measuring range 0.01 to 20 mg/l
- With Memosens technology
- Product Configurator on the product page: www.endress.com/ccs142d

 Technical Information TI00419C

Ion-selective sensors

ISEmax CAS40D

- Ion selective sensors
- Product Configurator on the product page: www.endress.com/cas40d

 Technical Information TI00491C

Turbidity sensors

Turbimax CUS51D

- For nephelometric measurements of turbidity and solids in wastewater
- 4-beam scattered light method
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cus51d

 Technical Information TI00461C

SAC and nitrate sensors

Viomax CAS51D

- SAC and nitrate measurement in drinking water and wastewater
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cas51d

 Technical Information TI00459C

Interface measurement**Turbimax CUS71D**

- SAC and nitrate measurement in drinking water and wastewater
- With Memosens technology
- Product Configurator on the product page: www.endress.com/cus71d



Technical Information TI00490C

Additional functionality**Hardware extension modules****Kit CM442R/CM444R/CM448R/CSF48: extension module AOR**

- 2 x relay, 2 x 0/4 to 20 mA analog output
- Order No. 71111053

Kit CM442R/CM444R/CM448R/CSF48: extension module 2R

- 2 x relay
- Order No. 71125375

Kit CM442R/CM444R/CM448R/CSF48: extension module 4R

- 4 x relay
- Order No. 71125376

Kit CM442R/CM444R/CM448R/CSF48: extension module 2AO

- 2 x 0/4 to 20 mA analog output
- Order No. 71135632

Kit CM442R/CM444R/CM448R/CSF48: extension module 4AO

- 4 x analog output 0/4 to 20 mA
- Order No. 71135633

Kit CM442R/CM444R/CM448R/CSF48: extension module 2DS

- 2 x digital sensor, Memosens
- Order No. 71135631

Kit CM442R/CM444R/CM448R/CSF48: extension module 2AI

- 2 x 0/4 to 20 mA analog input
- Order No. 71135639

Kit CM442R/CM444R/CM448R/CSF48: extension module DIO

- 2 x digital input
- 2 x digital output
- Auxiliary voltage supply for digital output
- Order No. 71135638

Kit CM442R/CM444R/CM448R/CSF48: extension module 485

- Ethernet configuration
- Can be extended to PROFIBUS DP or Modbus RS485 or Modbus TCP or EtherNet/IP. This requires an additional activation code which can be ordered separately.
- Order No. 71135634

Kit CM442R/CM444R/CM448R/CSF48/CA80: extension module ETH

- Ethernet configuration
- Can be extended to Modbus TCP or EtherNet/IP. This requires an additional activation code which can be ordered separately.
- Order No. 71279810

Upgrade kit CM442R/CM444R/CM448R/CSF48

- Extension module 485
- PROFIBUS DP (+ Ethernet configuration)
- Order No. 71140888

Upgrade kit CM442R/CM444R/CM448R/CSF48/CA80

- Extension module 485
- Modbus RS485 (+ Ethernet configuration)
- Order No. 71140889

Upgrade kit CM442R/CM444R/CM448R/CSF48/CA80

- Extension module 485
- Modbus TCP (+ Ethernet configuration)
- Order No. 71140890

Upgrade kit CM442R/CM444R/CM448R/CSF48

- Extension module 485
- EtherNet/IP (+ Ethernet configuration)
- Order No. 71219868

Upgrade kit CM442R/CM444R/CM448R/CSF48/CA80

- Extension module ETH
- Modbus TCP (+ Ethernet configuration)
- Order No. 71279809

Upgrade kit CM442R/CM444R/CM448R/CSF48

- Extension module ETH
- EtherNet/IP (+ Ethernet configuration)
- Order No. 71279812

Firmware and activation codes

SD card with Liquiline firmware

- Industrial Flash Drive, 1 GB
- Order No. 71127100



You must quote the serial number of the device when ordering the activation code.

Activation code for digital HART communication

Order No. 71128428

Activation code for PROFIBUS DP

Order No. 71135635

Activation code for Modbus RS485

Order No. 71135636

Activation code for Modbus TCP for module 485

Order No. 71135637

Activation code for EtherNet/IP for module 485

Order No. 71219871

Activation code for Modbus TCP for module ETH

Order No. 71279813

Activation code for EtherNet/IP for module ETH

Order No. 71279830

Kit CM442R: activation code for 2nd digital sensor input

Order No. 71114663

Kit CM444R/CM448R: upgrade code for 2 x 0/4 to 20 mA for BASE-E

Order No. 71140891

Activation code for feedforward control

- Requires current input or fieldbus communication
- Order No. 71211288

Activation code for measuring range switch

- Requires digital inputs or fieldbus communication
- Order No. 71211289

Activation code for ChemocleanPlus

- Requires relays or digital outputs or fieldbus communication and optional digital inputs
- Order No. 71239104

Software

Memobase Plus CYZ71D

- PC software to support laboratory calibration
- Visualization and documentation of sensor management
- Sensor calibrations saved in the database
- Order as per product structure, www.endress.com/cyz71d



Technical Information TI00502C

Field Data Manager Software MS20

- PC software for central data management
- Visualization of series of measurements and logbook events
- SQL database for secure data storage
- Order No. 71129799

Other accessories

External display**Graphic display**

- For installation in the control cabinet door or panel
- Order No. 71185295

Service display

- Portable, for commissioning
- Order No. 71185296

SD card

- Industrial Flash Drive, 1 GB
- Order No. 71110815

M12 built-in socket and cable junction with Velcro strip**Kit CM42/CM442R/CM444R/CM448R: external CDI socket**

- Socket with terminated connecting cables and counter nut
- Order No. 51517507

Kit CM442R/CM444R/CM448R/CSF48: M12 built-in socket for digital sensors

- Pre-terminated
- Order No. 71107456

Kit CM442R/CM444R/CM448R/CSF48: M12 built-in socket for PROFIBUS DP/Modbus RS485

- B-coded, pre-terminated
- Order No. 71140892

Kit CM442R/CM444R/CM448R/CSF48: M12 built-in socket for Ethernet

- D-coded, pre-terminated
- Order No. 71140893

Kit: external CDI socket, complete

- Retrofit kit for CDI interface, with terminated connecting cables
- Order No. 51517507

Cable junction with Velcro strip

- 4 pieces, for sensor cable
- Order No. 71092051

Communication-specific accessories**Commubox FXA191**

- Intrinsically safe HART communication with FieldCare via the RS232C interface
- Transforms HART signals on RS 232C interface



Technical Information TI00237F

Commubox FXA195

Intrinsically safe HART communication with FieldCare via the USB port



Technical Information TI00404F

Commubox FXA291

Connects the CDI interface of measuring devices with the USB port of the computer or laptop



Technical Information TI00405C

Wireless HART adapter SWA70

- Wireless device connection
- Easily integrated, offers data protection and transmission safety, can be operated in parallel with other wireless networks, minimum cabling complexity



Technical Information TI00061S

Fieldgate FXA320

Gateway for the remote interrogation of 4-20 mA measuring devices via a Web browser



Technical Information TI00025S

FieldXpert SFX100

Compact, flexible and robust industrial handheld terminal for remote configuration and for obtaining measured values via the HART current output

 Operating Instructions BA00060S

System components


RIA14, RIA16

- Field display unit for integration into 4-20 mA circuits
- RIA14 in flameproof metal enclosure

 Technical Information TI00143R and TI00144R

RIA15

- Process display unit, Digital display unit for integration into 4-20 mA circuits
- Panel mounting
- With optional HART communication

 Technical Information TI01043K

www.addresses.endress.com
